

Coil Discharge Bead Drum Instructions

How to install the Euromarc Elite 801 Beads to achieve superior results:

250KG

Coil Discharge
Bead Drum

1: Remove the Bead drum lid

Open the clamp fully and remove the lid



2: Remove the 4 packer blocks and the Silica Gel packet



3: Open the 3 bead bags and evenly distribute around the drum wire surface.



- 4:** Pull the end of the wire through the feeding hole at the top of the cap.
(Not Supplied)



- 5:** Assemble the feeder top to the Elite801 Coil Discharge Bead Drum
(Not Supplied)



WARNING: Electric shock can kill. Arc rays can injure eyes. Welding fumes are hazardous to your health and may damage lungs and other organs. Use adequate ventilation. Arc rays and sparks can injure eyes and burn skin. Wear correct hand, head, eye and body protection.

Read and understand the Safety Data Sheet for this product.

